Citymate
Self Balu

USER MANUAL

01

EN

Thanks for choosing our sea scooter!

Be sure to read this user manual thoroughly before using. Especially, "Safety risks" and "Storage conditions for the sea scooter" must be observed. In the manual, You will help you use and maintain the sea scooter more effectively.

02

Safety risks:

For your safety, before using the sea scooter, please be sure to wear a certified personal flotation device (PFD), check that the battery is fully charged and familiarize yourself with the hazards such as locations and obstacles in the water. Learn professional diving skills to master ascending and descending in operation.

Storage conditions for the sea scooter:

Please store this device with the battery pack in accordance with local laws and regulations. Remove the battery and store it in a safe place when the device is not in use. Always store and charge in a cool place.

Keep it in a cool place away from direct sunlight.

03

WARNING:

- Prior to use, please put on a swimming cap with all hair completely tucked inside! Loose hair poses a real entanglement in the propeller.
- Do not place your fingers in the propeller while the device is in operation.

- After use, please immerse the sea scooter in fresh water for 10 minutes, rinse it with fresh water, and wipe it clean with a dry towel. Do not clean the device with any detergents.

04

- Keep the battery oriented downward when replacing it.

- Always keep the connection between the battery and the device dry.

05

Structure Diagram

01 Upper cover
02 Weight can be added to ballast
03 Weight can be added for diving
03 Handle switch
04 Motor/Propeller
05 Battery latch
06 Battery
07 LED working indicator
08 Internal buoyancy foam
09 Handle
10 Safety net

06

Battery Installation

1. Insert the battery into the battery compartment as illustrated in the picture.

2. Secure the battery in place as shown.

07

3. Installation is complete.

Remove the battery in the reverse order

1. Open the battery latch.

2. Take out the battery.

08

Removal of Propeller Cover

- Rotate the water inlet grille counterclockwise to remove it, allowing you to clean away any weeds and foreign objects that may accumulate during use.

09

Installation of Propeller Cover

- Install the water inlet grille by turning it clockwise.

10

How to Use

- Turn on the red switch (as shown), place the sea scooter in the water, and press and hold the two handles simultaneously to start the motor.
- To stop the device, simply release the two handles. Turn off the red switch whenever the device is not in use.
- Please turn off the red switch whenever the device is not being used underwater.
- Please avoid operating the "sea scooter" for extended periods of time to prevent overheating of the motor. (The motor needs to cool underwater during operation.)

11

How to Use

- The "sea scooter" features two speed modes.
- When the device is turned on by pressing the switches simultaneously, the **Standard mode** will be activated by default, and the indicator will turn **green**.
- Release the switches simultaneously within 1 second, and then press them again to resume the **Standard mode**; the indicator will turn **green**.

- Release the switches simultaneously and press them again with in 1 second to activate the **Sports mode**; the indicator will turn **blue**.

12

Technical Specifications

Size(Length*Width*Height)	1000*350*350mm
Net weight	15.7kg(Without battery pack)
Battery capacity	6.4Ah,44.2V (V1.0MAX)
Max. speed	3.5km/h
Max. depth	30m(Recommended depth:≤20m)
Duration time	1.5h (V1.0)
Charging time	3.5h (V1.0)
Battery pack	Lithium-ion battery pack
Protection class	Lithium-ion battery pack

13

FAQ

- Can I change the battery underwater, or can I put the battery pack in water?

A: No, it's not safe. The connection between the battery pack and the motherboard could come loose.

- Why should the battery and the sea scooter be kept dry?

A: Make sure the connector between the battery and the motherboard is completely dry before storage; otherwise, it could be damaged by electrolytic oxidation upon power-on.

- Will the sea scooter sink?

A: No, it will float just above the surface of the water.

- Why is it necessary to immerse and rinse the sea scooter in fresh water after use?

A: Seawater contains salt crystals, sand particles, and other impurities. Prolonged exposure to it can lead to rust and cause corrosion. Therefore, it is essential to rinse the device with water a few minutes after diving. Delayed rinsing can cause these substances significantly exacerbated damage.

- Does the case that all four battery indicators are flashing simultaneously indicate a malfunction of the sea scooter?

A: Yes. The sea scooter has a self-repair feature. It will work again just release the switch and wait for the indicator to go out.

14

FAQ

- Why does the motor stop working after being powered on for a period of time?

A: It may be caused by the sand particles or crystals in the motor chamber. Please immerse the device in water for a few minutes, then run it continuously until the motor operates normally.

- Why won't the battery charge after the charging plug is connected?

A: The battery pack may become warm after use, so it should be left to cool down right away. Wait for it to cool down before charging.

- Will the speed decrease when the power decreases?

A: No. The speed will stay the same until the power is exhausted.

- Can I still use the battery pack if the case is damaged?

A: No. We suggest that you reach out to your local dealer to replace the battery pack.

- Is this sea scooter waterproof?

A: Yes. The battery and the connector between the motor and the motherboard are both waterproof. Water will be absorbed by the body during use.

15

Warning

① This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

② Children should be supervised to ensure that they do not play with the appliance.

③ Rechargeable batteries containing them should be taken to separate recycling or household hazardous waste collection points. To prevent fires, the battery terminals should be taped with insulating material before disposal. The battery compartment should be placed in a separate sheath bag to isolate the terminals.

④ If the battery leaks fluid, take the leaking battery to a recycling center that accepts hazardous waste. Do not discard it with regular household garbage.

⑤ — This appliance contains batteries that are only replaceable by professionals.

— In rechargeable batteries are to be removed from the appliance before being charged.

— Rechargeable batteries are to be removed from the appliance and safely disposed of.

— If the appliance is to be stored unused for a long period, the batteries should be removed.

— Do not use non-rechargeable batteries in place of rechargeable batteries.

— Do not mix different types of batteries.

⑥ — The battery type reference.

— the orientation of the battery with regard to polarity.

— How to remove the battery, if applicable, during maintaining correct polarity.

⑦ **WARNING**: Use only with GM65-2942DC-D Battery charger.

16

TR

Su planörü seçtiğiniz için teşekkür ederiz!

Su planörü kullanmadan önce bu kullanım kılavuzunu okumanız önemlidir. Tüm önlemleri ve kullanım kılavuzunda belirtilen "Güvenlik riskleri" ve "Su planörü depolama koşulları"na uyulmalıdır. Bu kılavuz, su planörünü daha etkili bir biçimde kullanmanıza ve bakımını yapmanıza yardımcı olur.

17

Güvenlik riskleri:

Kendi güvenliğiniz için, kullanmadan önce mutlaka onaylı kişisel yüzdürme cihazı (PFD) giyin, pilin tam şarjlı olduğundan emin olun, Ayrıca, su altındaki lokma, engel gibi tehlikeleri önceden öğrenin. Profesyonel dalış becerilerini öğrenerek çıkma ve inme, alçalma gibi operasyonları gerçekleştirin.

Su planörü depolama koşulları:

Bu cihazı batarya takımı içeriğinden, yerel yasa ve düzenlemelere uygun şekilde depolayın. Cihazı kullanmadığınız zamanlarda pili çıkarın ve güvenli bir yerde ayrı olarak depolayın. Güneş ışığından doğrudan uzak, serin bir alanda depolayın.

18

Uyarı:

- Kullanmadan önce lütfen yüzme boneği takın ve saçlarınızı dışarıda bırakmayın. Pervaneye kapılmalara için.

- Cihaz çalışırken lütfen parmaklarınızı pervaneye sokmayın.

- Kullanımdan sonra lütfen su planörü tatlı suda 10 dakika bekletin, tatlı suyla durulayın ve kuru bir havluyla temizleyin. Deterjan kullanmayın.

19

- Bataryayı değiştirirken, pilin uzunu aşağı bakacak şekilde tutun.

- Bataryayı cihaz bağlı olduğu yerde daima kuru tutun.

20

Yapı Şeması

01 Üst Kapak
02 Kamera Braketi (ileriş için ağırlık eklenebilir)
03 Tutamak Anahtarı
04 Motor/Pervaneye
05 Batarya Mandalı
06 Bataryа
07 Çalışma LED Göstergesi
08 İç Yüzdürme Köpüğü
09 Tutamak
10 Dokunma Ağı

21

Batarya Kurulumu

1. Bataryayı şekilde gösterildiği gibi pil yuvasına yerleştirin.

2. Bataryayı kilitleyerek sabitleyin, şekilde gösterildiği gibi.

22

3. Kurulum tamamlandı.

Bataryayı çıkarın, tersini yapın

1.Bataryanın mandalını açın

2. Bataryayı çıkarın.

23

Pervaneye kapağını sökün

- Su giriş ızgarasını saat yönünün tersine çevirerek çıkarın ve kullanım sırasında biriken yabancı otları ve yabancı maddeleri temizleyin.

24

Pervaneye kapağını sökün

- Su giriş ızgarasını saat yönünde çevirerek kurulum

25

Nasıl kullanılır

- Kırmızı anahtarı açın (resimde gösterildiği gibi), su planörü suya yerleştirin ve pervaneye etkinleştirmek için her iki kolu aynı anda basın.
- Çalışmayı durdurmak için her iki kolunuzu da serbest bırakmanız yeterlidir ve kullanılmadığında daima kırmızı anahtarı kapatın.
- Su altında kullanılmadığında kırmızı anahtarı her zaman kapatın.
- Lütfen su altı dışı ortamlarda "su planörü" ni uzun süre çalıştırmayın. (Motor çalışırken su altında soğutulması gerekir)

26

Nasıl kullanılır

- "Su planörü"nü iki hız modu vardır.
- Anahtarları aynı anda basılı tutun, açıldıktan sonra varsayılan olarak **standart mod**, ışık şu şekilde yanar **yeşil**

- Anahtarları aynı anda bırakın ve 1 saniye içinde tekrar basın: **spor mod**, ışık şu şekilde yanar **mavi**

27

Technical Specifications

Size(Length*Width*Height)	1000*350*350mm
Net weight	15.7kg(Without battery pack)
Battery capacity	6.4Ah,44.2V (V1.0MAX)
Max. speed	3.5km/h
Max. depth	30m(Recommended depth:≤20m)
Duration time	1.5h (V1.0)
Charging time	3.5h (V1.0)
Battery pack	Lithium-ion battery pack
Protection class	Lithium-ion battery pack

28

FAQ

- Bataryа su altında değişmelidir veya bataryа takımın suya girmesine izin verin?

A: Hayır, pilin kısa devre olmasına bataryа takımının ile arasındaki konektörlerin bağlantısı kesilecek

- Bataryа ve su planörü neden kuru tutulmalıdır?

A: Depolama öncesi pil ve arasındaki konektörlerin tamamen kuru olduğundan emin olun, aksi takdirde güç verildiğinde elektronik oksidasyon nedeniyle hasar görürler.

- Su planörü suya batar mı?

A: Hayır, suyun üzerinde hafifçe yüzecektir.

- Su planörü kullanıldıktan sonra neden tatlı suda bekletmem ve durulamam gerekiyor?

A: Deniz suyunda kul kristalleri, kum parçacıkları ve yüzme nesnelerinde kirlerbi bulunur ve bunların hepsi korozyona neden olur. Bu nedenle cihazı kullandıktan sonra tatlı su içinde ve iki durulama yapılması çok önemlidir. Koruyucu neden olabilecek maddeleri ne kadar geç uzaklaştırılmanız, bu maddelerin verdiği hasar artacaktır.

- Tüm bataryа göstergesi ışık ayını anda yanıp sönüyorsa, su planörü bir arıza mı var?

A: Evet, bataryа, motor ve anahart konektörleri su geçirmezdir. Kullanım sırasında su cihaz içine girebilir.

29

Warning

① Bu cihaz, fiziksel, duyusal veya zihinsel yetilerinin eksik olduğu (çocuklar dahil) kişilerden kullanılmak üzere tasarlanmamıştır.Denetim veya cihazın güvenliğinden sorumlu bir kişi tarafından cihazın kullanımı ile ilgili talimatlar verilmedikçe veya bu kişi tarafından gözetim altında tutulmadıkları sürece.

② Çocukların birlikte oynamalarından emin olmak için çocuklar denetlenmelidir.

③ - Bunları içeren piller ve cihazlar, geri dönüşüm veya hane halkı tehlikeli atık toplama noktalarına götürülmelidir. Yangınları önlemek için, pil terminalleri bertaraftan önce bant ile izolatör kaseti ile bantlanmalı veya terminaller izole etmek için her pil için bir ayrı bir torbaya yerleştirilmelidir.

④ If the battery leaks fluid, take the leaking battery to a recycling center that accepts hazardous waste. Do not discard it with regular household garbage.

⑤ — Cihazı veya pil-şarj kısımlarını mahvet mi mahvetmez.

— Pil tarafından çalışan cihazın terminalleri veya pilin metal kısımlarına dokunmayın. Yangın veya patlama riski oluşturabilir.

⑥ Bu cihaz, yalnızca yetkevli kişiler tarafından değiştirilmesi gereken piller içerir.

— Şarj edilebilir piller, şarj edilmeden önce cihazdan çıkarılmalıdır.

— Şarj edilebilir piller cihazdan ve güvenli şekilde atılmalıdır.

— Cihaz uzun süre kullanılmayacaksa pillerin çıkarılması gerekir.

— Şarj edilebilir piller yerine değiştirilemeyen piller kullanmayın.

— Değiştirilmiş veya hasarlı piller kullanmayın.

⑦ Pil tipi referans.

— Pilin polarite açısından yönü.

— Bakım yapılırken, varsa pilin nasıl çıkarılacağı.

⑧ **Uyarı:** Yalnızca GM65-2942DC-D Pil Şarj Cihazı ile kullanın.

30